

How to Clean Cooker Canopy Filters

Important: never use equipment with baffle filters removed. Seek professional advice if damaged, faulty or ill-fitting.

Routine maintenance

- Cool down range equipment.
- Remove filters.
- Spray all surfaces, with approved degreaser solution. If possible allow to soak overnight.
- On heavily soiled areas where grease is baked-on, scrub soil with a brush until grease and soil are dissolved or loosened.
- Clean and remove debris/grease from the channels that hold the filters.
- Flush off soil and solution with clear, hot water. Allow inside surfaces to air dry. Wipe outside surfaces.
- Replace clean filters. Return clean filters to original positions.